

Troubleshooting Steps

Opening the key storage compartment door

1. Open shutter door to reveal the dials and the release button
2. Rotate dials to the current combination (if the lock is new, the combination is set at the factory to 0-0-0-0)
3. Press down on the release button to open the door

Closing the key storage compartment door

1. Close compartment door
2. Scramble the combination dials to lock the door and conceal your combination
3. Close the shutter door

To set a new combination:

The initial combination is set at the factory to 0-0-0-0

1. Open the compartment door (see instructions above)
2. Push the reset lever left and down. The lever remains in this position
3. Rotate dials to your desired combination
4. Push the reset lever, up and right, back to the original position
5. Close the key storage compartment door
6. Scramble the combination dials to lock the door and conceal your combination
7. Close the shutter door