


Learning CUBE

INTRODUCTION

The **Learning Cube** is an interactive and educational toy intended for toddlers and early learners. Stimulate your little one to a whole new way of learning the alphabet, numbers, colors, songs of the alphabet, numbers and colors, entertaining animal sounds, instrument sounds, and lovely music!
(6+ months)



INCLUDED IN THIS PACKAGE

- 1 interactive **Learning Cube**.

ADVICES

- For best performance, please make sure to turn the unit OFF before inserting or removing batteries. Otherwise, the unit may malfunction.
- All packing materials, such as tape, plastic, sheets, packaging locks, wire ties and tags are not part of this toy, and should be discarded for your child's safety.
- Please keep this user's manual as it contains important information.
- Please protect the environment by not disposing of this product with household waste.


GETTING STARTED

Take the **Learning Cube** out of the storage slot.

Battery Installation


The **Learning Cube** operates on 3 AAA (LR03) batteries:

1. Locate the battery cover of the unit and open it with a screwdriver.
2. Insert 3 AAA (LR03) batteries as illustrated.
3. Close the battery cover securely.



Start Playing

Once batteries are installed, switch on the power from **○** to **)** or **)))**. Then press any of the buttons to play!



SLEEPING MODE

If the **Learning Cube** is not active for more than 2 minutes, it will automatically go into the sleeping mode to save power.

Press any button to wake up the **Learning Cube**.

We recommend switching the unit OFF when done playing with it.

FUNCTIONAL BUTTONS

ALPHABET



Learn the alphabet A~Z and play the alphabet song.

*"A B C D E F G H I J K L M N O P
Q R S and T U V W X Y and Z*

*now I know my ABCs won't you sing along with me
(now I know my ABCs next time won't you sing with me)"*

NUMBER



Learn the number 1~10 and play the number song.

*"I say one two three (you say one two three)
you say four five six (I say four five six)
the next is seven eight nine and ten*

*we do the counting count together from one to ten
let's do it again! (now we can count aloud!)"*

COLOR



Learn the colors as the LED lights up
and play the color song.

*"red yellow green and blue green and blue
shiny orange and purple too
all the colors that we know live up in the rainbow"*

MUSIC



Play 10 fun music.

★ *Tip: Play music with the musical instrument button or
animal button at the same time to hold a little concert!*

MUSICAL INSTRUMENT



Play 12 instrument sounds.

Drum

Shaker

Cymbal

Castanet

Triangle

Tambourine

★ *Tip: Hold on the button, discover more hidden sounds!*

ANIMAL



Play 15 entertaining animal sounds.

Bird

Bear

Cat

Cow

Dog

Duck

Elephant

Frog

Horse

Leopard

Monkey

Owl

Rooster

Sheep

Tiger

CARE AND MAINTENANCE

- Keep product away from foods and beverages.
- Clean with a slightly damp cloth (cold water) and mild soap.
- Never submerge the product in water.
- Remove batteries during prolonged storage.
- Avoid exposing product to extreme temperatures.

BATTERY SAFETY

- Batteries are small parts and choking hazards to children, must be replaced by an adult.
- Follow the polarity (+/-) diagram in the battery compartment.
- Promptly remove dead batteries from the toy.
- Dispose of used batteries properly.
- Remove batteries from prolonged storage.
- Only batteries of the same type as recommended are to be used.
- **DO NOT** incinerate used batteries.
- **DO NOT** dispose of batteries in fire, as batteries may explode or leak.
- **DO NOT** mix old and new batteries.
- **DO NOT** mix alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH) batteries.
- **DO NOT** recharge non-rechargeable batteries.
- **DO NOT** short-circuit the supply terminals.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.

TROUBLESHOOTING

Symptom	Possible Solution
Toy does not turn ON or does not respond.	<ul style="list-style-type: none">● Make sure batteries are correctly installed.● Make sure battery cover is securely attached.● Remove batteries and put them back in.● Clean battery compartment by rubbing lightly with a soft eraser and then wiping with a clean dry cloth.● Install new batteries.
Toy makes strange sounds, behaves erratically or makes improper responses.	<ul style="list-style-type: none">● Clean battery contacts per above instructions.● Install new batteries.

Item No. 1021
Printed in China

CONFORMS TO
CE EN71
ASTM F963

